



START & STOP MANAGEMENT KITS CATALOGUE 2023



CONTENIDO

<u>CITROËN</u>	<u>3</u>
<u>FIAT</u>	<u>4</u>
<u>FORD</u>	<u>5</u>
<u>IVECO</u>	<u>6</u>
<u>NISSAN</u>	<u>7</u>
<u>OPEL</u>	<u>8</u>
<u>PEUGEOT</u>	<u>9</u>
<u>RENAULT</u>	<u>10</u>
<u>TOYOTA.....</u>	<u>11</u>

CITROËN START & STOP MANAGEMENT KITS



Vehicle	OEM Option Required	Positive Signal taken from Unit	Positive Signal taken from clutch
Jumpy 2.0 Blue Hdi	-	1182000412	1181000412
Jumper 2.0 & 2.2 BlueHdi	Jl01 (15 ways connector CO36L1A)	1183000514	

() In case of doubt, get the kit where the + signal is taken from the compressor clutch*

FIAT START & STOP MANAGEMENT KITS

FIAT



Vehicle	OEM Option Required	Positive Signal	
		taken from Unit	taken from clutch
Doblo Cargo 1.4 MPI	081 (15 ways connector CO36L1A)	1183000415	
Doblo Cargo 1.4 T-Jet 120		1183000415	
Doblo Cargo 1.6 Multijet II		1183000415	
Talento 2.0 dCi (Engine M9R)	8LM	1182000300	1181000300
Ducato 2.3 Multijet 2	081 (15 ways connector CO36L1A)	1183000514	
Ducato 2.2 Multijet 3		1183000514	

() In case of doubt, get the kit where the + signal is taken from the compressor clutch*

FORD START & STOP MANAGEMENT KITS



Vehicle	OEM Option Required	Positive Signal taken from Unit	Positive Signal taken from clutch
Transit Connect 1.5	-	1182000419	1181000419
Transit Custom 2.0 FWD			
Transit 2.0 FWD & RWD			

() In case of doubt, get the kit where the + signal is taken from the compressor clutch*

IVECO START & STOP MANAGEMENT KITS

IVECO



Vehicle	OEM Option Required	Positive Signal taken from Unit	Positive Signal taken from clutch
Daily 2.3	-	1182000400	1181000400

() In case of doubt, get the kit where the + signal is taken from the compressor clutch*

NISSAN START & STOP MANAGEMENT KITS



Vehicle	OEM Option Required	Positive Signal taken from Unit	Positive Signal taken from clutch
NV300 2.0 dCi	WRADA	1182000300	1181000300
NV400 2.3 dCi			

() In case of doubt, get the kit where the + signal is taken from the compressor clutch*

OPEL START & STOP MANAGEMENT KITS



Vehicle	OEM Option Required	Positive Signal taken from Unit	Positive Signal taken from clutch
Vivaro 1.6 CDTi (1)	UF3	1182000300	1181000300
Movano 2.3 CDTi (1)		1182000300	1181000300
Vivaro 1.5 & 2.0 Blue Hdi (2)	-	1182000412	1181000412
Movano 2.2 Blue Hdi (2)	JI01 (15 ways connector CO36L1A)	1183000514	

(1) Renault Platform / (2) PSA Platform

(*) In case of doubt, get the kit where the + signal is taken from the compressor clutch

PEUGEOT START & STOP MANAGEMENT KITS



Vehicle	OEM Option Required	Positive Signal taken from Unit	Positive Signal taken from clutch
Expert 2.0 Blue Hdi	-	1182000412	1181000412
Boxer 2.0 & 2.2 BlueHdi	Jl01 (15 ways connector CO36L1A)	1183000514	

() In case of doubt, get the kit where the + signal is taken from the compressor clutch*

RENAULT START & STOP MANAGEMENT KITS



RENAULT



Vehicle	OEM Option Required	Positive Signal taken from Unit	Positive Signal taken from clutch
Kangoo 1.5	CABADP	1182000300	1181000300
Trafic 2.0 dCi			
Master 2.3 dCi			

() In case of doubt, get the kit where the + signal is taken from the compressor clutch*

TOYOTA START & STOP MANAGEMENT KITS



Vehicle	OEM Option Required	Positive Signal taken from Unit	Positive Signal taken from clutch
Proace 2.0 Blue Hdi	-	1182000412	1181000412

() In case of doubt, get the kit where the + signal is taken from the compressor clutch*